



Identificación de eventos SP1600

Evento	NT ID	ID evento	Estado 0	ID evento	Estado 1
Rest	0	0	To moving	80	To rest
GSM antijamming	1	1	To normal	81	To jamming
Geo-fence	2	2		82	Enable
GPS TTF	3	3		83	Enable
Fiber disconnected	4	4		84	Enable
SOS	5	5		85	Enable
Tag low voltage	6	6		86	Enable
Tag under voltage	7	7		87	Enable
Device low voltage	8	8		88	Enable
Device under voltage	9	9		89	Enable
Tag entering	10	A		8A	Enable
Tag leaving	11	B		8B	Enable
Balance notice	12	C	To stand	8C	Enable
Body gesture	13	D	To stand	8D	To lying
					Start
Charging	14	E	Stop	8E	
...
Combo 0	56	38		B8	
Combo 1	57	39		B9	
Combo 2	58	3A		BA	
Combo 3	59	3B		BB	
Combo 4	60	3C		BC	
Combo 5	61	3D		BD	
Combo 6	62	3E		BE	
Combo 7	63	3F		BF	